EUREKA®

Hot Plate Electric Griller

INSTRUCTION MANUAL

EEG HP



PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE APPLIANCE

Please read the instruction carefully before using

1. Temperature regulator:
   - 5 stages temperature regulator can be set to the highest temperature of 250°C
2. This product use Teflon paint, have excellent heat transfer performance. The pan has an oil outlet, making it more convenient to use.
3. Use the temperature regulator to adjust the heat—this product can reach up to 240°C.
4. The electronic pan needs to preheat before use. It will heat to the temperature you set.
5. The indicator light will turn off automatically and stop heating once it reaches the set temperature.

Specification

ITEM NAME	EUREKA HOT PLATE ELECTRIC GRILLER
ITEM CODE	EEG HP
RATED VOLTAGE	230V a.c.
RATED FREQUENCY	60 Hz
RATED POWER	1500 W
UNIT DIMENSION	470 x 235 x 90 mm
BOX DIMENSION	490 x 270 x 120 mm
GROSS / NET WEIGHT	2.6 kg / 1.6 kg

Attention

- This product is 230V power supply product.
- This product can't be use together with any other electronic product on a same power outlet.
- Keep children away from this product while it is in use.
- Please connect the temperature regulator before plugging it into the power supply.
- Don't move the product while using.
- Do not use this product near flammable materials.
- Do not leave the product unattended while it is heating.
- Do not insert the temperature regulator or leave the product heating for a long time when not in use.
- Please avoid twisting the power cords or damaging their insulation.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Operation Procedure

- Step 1: Prepare the material
- Prepare all the meat and vegetables for the cooking.
- Step 2: Prepare the electronic pan
- Please use the electronic pan in a smooth and safe place.
- Step 3: Connect the temperature regulator
- Please connect the temperature regulator before plugging it into the power supply.
- Please confirm if the temperature regulator is OFF.
- Notice: Please don't drop the temperature regulator.
- Hold the temperature regulator body when you pull it out.
- Step 4: Enjoy grilling!
- Notice: Please ensure the product is placed on a stable, level surface. If the pan tilts during use, it may cause a risk of burns.

Fault Judgement and Simple Maintenance

Fault phenomenon	Fault reason	Handling method
The power indicator light is not bright	1. The power outlet is not connected to to the power supply 2. The temperature regulator and power cord is damaged	1. Ask qualified electrician to fix. 2. Purchase the temperature regulator from the specify maintenance department or the manufacturer (this part is not suitable for maintenance)
The electronic pan is not working	1. The temperature regulator is not connected properly. 2. The temperature regulator connector is too loose.	1. Please connect again to reach the designated position 2. Purchase the temperature regulator from the specify maintenance department or the manufacturer (this part is not suitable for maintenance)
The pan body's temperature is lower	1. Temperature regulator is not poisitioned properly. 2. Temperature regulator is damaged.	1. Adjust the temperature regulator again, adjust to a fit temperature. 2. Purchase the temperature regulator from the specify maintenance department or the manufacturer (this part is not suitable for maintenance)
Bottom of the pan has a slight white smoke emitted and slight noisy	1. Insulation materials caused by heating for the first time.	It is normal it will disappear in 5-10 minutes.

If the above method is still can't solve the problem, please send the product to the Authorized Service Center for repair, please don't tear down the product by yourself.

- Reference: The temperature regulator power supply will turn on to turn off again and again when you are using, according to heating condition.
- Warning: Don't let you finger touch to the electronic pan.
- Notice：Don't use the sharp metal tools when you are at the barbecue, it will damage the surface of the pan. When the pan in the hot state,don't put the plastic and objects such as easy to melt in the pan. You need to adjust the temperature regulator to the left end once you finish using, then pull out the plug. Don't touch the pan when the it in the hot state. You must have your pan cooled sufficiently before moving and clean it, pull out the temperature regulator lightly after the pan cooled sufficiently. Warning: Must pull out the plug when you are not using and clean the pan, avoiding the temperature regulator get wet by water.
- Must have your pan cooled sufficiently after pulling out the plug.
- Must pull out the temperature regulator.
- Avoiding the temperature regulator fell into water or washed in the water.
- Please use soft dry duster cloth and dry tissue to wipe the temperature regulator.
- Please use duster cloth wipe the pan after barbecue.
- Please don't let the temperature regulator socket part touch water when cleaning.
- Please use soft dry duster cloth and dry tissue to wipe.
- Make sure the product is in the completely dry condition before using, must make sure the temperature regulator socket part is in the dry condition.
- Don't use rough objects,such as iron brush wipe the pan, it will scratch the paint on the surface of the pan.

EUREKA®

Thank you for patronizing our products!

For more comments and suggestions,
please call our hotline numbers:

0998 584 2057 / 0917 814 5356

EUREKA ELECTRIC APPLIANCES PHILIPPINES CORP.
E. Rodriguez Rd., Oxford Compd., Brgy. Sta. Rosa I, Marilao, Bulacan

eurekahomeappliances.com
EurekaHomeAppliances
eurekahomeappliancesph
eurekahomeappliances