

EUREKA[®]

20" Cyclone Pro Floor Fan

INSTRUCTION MANUAL

EFF 20




**BEFORE USING THE APPLIANCE
PLEASE READ CAREFULLY THIS MANUAL**

CAUTION:

1. Do not plug line cord into outlet until fan has been completely assembled.
2. Use only with rated voltage.
3. During operation, don't put your hands or any other objects inside the guard.
4. Do not attempt to force the louver to turn.
5. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid hazard.
6. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
7. Children should be supervised to ensure that they do not play with the appliance.

ASSEMBLY:

Before using the unit, parts should be installed properly, install it in the direction shown by the arrow, you will hear a snapping sound, once installed. Otherwise the appliance will be easily overturned.



SPECIFICATION:


Power Supply : 230V a.c. 60Hz

Power: 140W

SPEED CONTROL:

To turn on the fan, simply turn on the Rotary Switch to (1, 2 or 3).

To turn it off, switch it to “0”.



Cleaning:

When cleaning the unit, it is necessary to pull the plug, only use dry cloth or soft cloth soaked with soap and water.

Maintenance:

1. Keep this unit in cool dry place.
2. Keep the fan clean, use a piece of soft cloth soaked with soap and water to clean off the dust and stains, wipe dry to keep in a fresh appearance.
Must not attempt to use solvents like thinner gasoline, etc.
3. After the fan is cleaned, pack it into a vinyl bag and store it in a dry place.

Note: Only applicable to model with timer. Above specifications are subject to change without notice.



You can help protect the environment!
Please remember to respect the local regulations:
hand in the non-working electrical equipments to
an appropriate waste disposal center.

EUREKA[®]

Thank you for patronizing our products!

For more comments and suggestions,
please call our hotline numbers:

0998 584 2057 / 0917 814 5356

EUREKA ELECTRIC APPLIANCES PHILIPPINES CORP.

E. Rodriguez Rd., Oxford Compd., Brgy. Sta. Rosa I, Marilao, Bulacan



 eurekahomeappliances.com

 EurekaHomeAppliances

 [eurekahomeappliancesph](https://www.instagram.com/eurekahomeappliancesph)

 [eurekahomeappliances](https://www.youtube.com/eurekahomeappliances)